







































































Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	8		8
	5		5
	6		6
	7		7
	9		9
	0		0
	Source		AV
	Recall		Pre Ch
	Menu		Menu
	Exit		Exit
	[<>]		Format
	→□←		3D
	OK		Ok
	Up		Up
	P+		Ch +
	P-		Ch -
	Down		Down
	Right		Right
	Vol+		Vol +
	Left		Left
	Vol-		Vol -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[i+]		Info
	Swap		Sleep
	O)/I/II		Dual





Original		Substitut		Original		Substitut	
	[≡?]		GUIDE				
	[▼]		HOME SMART				
	[■]/[]		SETTINGS OPT				
	[≡i]		APP MEDIA				
	[≡]		REPEAT TEXT				
	[≡o]		AD SUBT				
	[O]/[≡x]		SEARCH TV/R				
	[≡♦]		ZOOM				
	[≡+]		SHIFT + ECO 3D				

