









































































































Original	Substitut	Original	Substitut
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 Source	 AV
 1	 1	 Enter	 Ok
 2	 2	 Up	 Up
 3	 3	 Down	 Down
 4	 4	 Left	 Left
 5	 5	 Right	 Right
 6	 6	 Exit	 Exit
 7	 7	 Display	 Shift + Info
 8	 8	 Vol+	 Vol +
 9	 9	 Vol-	 Vol -
 0	 0	 CH+	 Ch +
 DTV/ATV	 Info	 CH-	 Ch -
 Recall	 Pre Ch	 MTS	 Shift + Sleep
 P.Mode	 Shift + Format	 Rec List	 D. Menu
 S.Mode	 Shift + Dual	 FAV/List	 Dual
 Sleep	 Sleep	 Rec	 Rec

Original	Substitut	Original	Substitut
 Menu	 Menu	 Source	 AV
 Enter	 Ok	 Up	 Up
 Down	 Down	 Left	 Left
 Right	 Right	 Exit	 Exit
 Display	 Shift + Info	 Vol+	 Vol +
 Vol-	 Vol -	 CH+	 Ch +
 CH-	 Ch -	 MTS	 Shift + Sleep
 Rec List	 D. Menu	 FAV/List	 Dual
 Rec	 Rec		





Original	Substitut	Original	Substitut
	Freeze		Options
	<</Guide		<<
	>>/Aspect		>>
	I<</Cancel	+	Shift + Subt
	>>I/Sub.Pg		Back
	Stop/Index		Stop
	Play/Pause/Time Shift		Play
	Tv/Radio		TV/R
	Subtitle		Subt
	Reveal	+	Shift + Options
	Size		Format
	Hold		Eject
	Text		Text
	Red		Red
	Green		Green
	Yellow		Yellow
	Cyan		Blue

Original	Substitut

