







































































| Original   | Substitut  | Original  | Substitut  |
|--|--|---|--|
|  Power  |  Power                |  Exit        |  Exit / Cancel / Clear    |
|  Mute   |  Mute / Dimmer        |  Up          |  Up                       |
|  1      |  1                    |  Down        |  Down                     |
|  2      |  2                    |  Right       |  Right                    |
|  3      |  3                    |  Vol+        |  Vol+                     |
|  4      |  4                    |  Vol-        |  Vol-                     |
|  5      |  5                    |  Left        |  Left                     |
|  6      |  6                    |  OK          |  OK                       |
|  7      |  7                    |  Tv/Rad      |  TV/Radio /               |
|  8      |  8                    |  Page Up     |  CH+ / Page+              |
|  9    |  9                  |  Page Down |  CH- / Page-            |
|  0    |  0                  |  HDMI/RES  |  Shift + 0              |
|  FAV  |  Fav / Marker / PC  |  HDMI/RES  |  AV / Input / RDS       |
|  Info |  Info / Angle       |  Ratio     |  Picture / Format       |
|  Menu |  Menu / Home        |  Red       |  Red / Netflix / Search |
|  Back |  Back / Return      |  SOS       |  D.Menu / Top           |
|  EPG  |  Guide / EPG / -/-- |  SUB       |  Subtitle / EQ          |





| Original  | Substitut   | Original | Substitut                   |
|---|---|----------|-----------------------------|
|  LANG        | Green<br> APP<br>REPEAT          |          | Green / APP / Repeat        |
|  LANG        | Lang.<br> LANG I/II<br>AUDIO     |          | Audio / Lang I/II           |
|  Yellow      | Yellow<br> YouTube<br>REPEAT A-B |          | Yellow / YouTube / Repeat   |
|  TXT         | Blue<br> Prime Video<br>RANDOM   |          | Blue / Prime Video / Random |
|  TXT         | TXT<br> GOTO<br>TEXT             |          | Text / Goto                 |
|  TIMER       | Timer<br> TIMER<br>SLEEP         |          | Sleep / Timer               |
|  MEDIA       | Media<br> MEDIA<br>DISPLAY       |          | Display / Media             |
|  Rec         | Rec<br> REC MODE                 |          | Rec / Rec Mode              |
|  LIST<br>USB | USB/List<br> LIST<br>SMART       |          | Smart / List                |
|  Play        | Play<br> SLOW                    |          | Play / Slow                 |
|  Pause      | Pause<br> STEP-FREEZE           |          | Pause / Step / Freeze       |
|  Stop      | Stop<br> HOLD                  |          | Stop / Hold                 |
|  >>        | >><br> TUNE+                   |          | >> / Tune+                  |
|  <<        | <<<br> TUNE-                   |          | << / Tune-                  |
|  >>        | >> <br> PRESET+                |          | >>  / Preset+               |
|   <<       | <<<br> PRESET-                 |          | << / Preset-                |
|  Nothing   | Nothing<br> OPT-TOOLS<br>SETUP |          | Setup / OPT /               |

