







































Original		Substitut		Original		Substitut	
	Power		Power		0		0
	Mute		Mute / Dimmer				
	Tv Input		AV / Input / RDS				
	Q.View		Menu / Home				
	Vol+		Vol+				
	PR+		CH+ / Page+				
	Vol-		Vol-				
	PR-		CH- / Page-				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				

