



Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	T		TV/R
	List		List
	Vol+		Vol +
	Vol-		Vol -
	[i]		Info

Original	Substitut	Original	Substitut
	*		Menu
	P+		Ch +
	P-		Ch -
	Home		Smart
	≡		Options
	←		Back
	Source		AV
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Exit		Exit
	Text		Text
	O)/Lang		Dual
	Guide		Guide
	Subt.		Subt





Original	Substitut
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 <<	 <<
 Pause	 Pause
 >>	 >>
 Play	 Play
 Stop	 Stop
 Zoom	 Eject
 Netflix	 Media

Original	Substitut

