












































































Original	Substitut	Original	Substitut
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 EPG	 Guide
 1	 1	 Exit	 Exit
 2	 2	 Up / CH + / I<<	 Up
 3	 3	 Down / CH - / >>I	 Down
 4	 4	 Right / Vol +	 Right
 5	 5	 Left / Vol -	 Left
 6	 6	 OK	 Ok
 7	 7	 Up / CH + / I<<	 I<<
 8	 8	 Down / CH - / >>I	 >>I
 9	 9	 Up / CH + / I<<	 Ch +
 0	 0	 Down / CH - / >>I	 Ch -
 FAV	 Shift + Pre Ch	 Left / Vol -	 Vol -
 Recall	 Pre Ch	 Right / Vol +	 Vol +
 Game	 Media	 Red / Zoom	 Red
 Auto	 Smart	 Green / Lan/Audio	 Green
 Info	 Info	 Yellow /	 Yellow

Original	Substitut	Original	Substitut
 MUTE	 MUTE	 TV	 AUX
 MUTE	 MUTE	 DVD	 REC MODE
 1	 1	 SAT	 PLAY MODE
 2	 2	 AUX	 II
 3	 3	 GUIDE	 ■
 4	 4	 CLEAR EXIT	 ●
 5	 5	 Up / CH + / I<<	 <<<
 6	 6	 Down / CH - / >>I	 <<
 7	 7	 Right / Vol +	 >>
 8	 8	 Left / Vol -	 >>>
 9	 9	 OK	 LIST
 0	 0	 Up / CH + / I<<	 DUAL
 FAV	 Shift + Pre Ch	 Down / CH - / >>I	 SUBT
 Recall	 Pre Ch	 Up / CH + / I<<	 OPT
 Game	 Media	 Down / CH - / >>I	 SLEEP
 Auto	 Smart	 Left / Vol -	 TV/R
 Info	 Info	 Right / Vol +	 FORMAT
		 Red / Zoom	 3D
		 Green / Lan/Audio	 D.MENU
		 Yellow /	 TEXT
			 ZOOM
			 TIMER
			 AV



