




























































































Original	Substitut	Original	Substitut
 INFO [i+]/REVEAL [?]	 Info / Angle	 <	 Left
 [+]	 Zoom / Size	 OK	 OK
 POWER	 Power	 >	 Right
 <<	 << / Tune-	 RETURN	 Back / Return
 PLAY	 Play / Slow	 V	 Down
 PAUSE	 Pause / Step / Freeze	 Tools	 Setup / OPT /
 >>	 >> / Tune+	 Menu	 Menu / Home
 SYNC MENU	 D.Menu / Top	 RED	 Red / Netflix / Search
 STOP	 Stop / Hold	 GREEN	 Green / APP / Repeat
 THEATRE	 Picture / Format	 YELLOW	 Yellow / YouTube / Repeat
 DIGITAL	 Display / Media	 BLUE	 Blue / Prime Video / Random
 ANALOG	 Smart / List	 1	 1
 SUBTITLE [...]	 Subtitle / EQ	 2	 2
 AUDIO	 Audio / Lang I/II	 3	 3
 GUIDE	 Guide / EPG / -/--	 4	 4
 ^	 Up	 5	 5
 Source	 AV / Input / RDS	 6	 6





	Original	Substitut		Original	Substitut
	7	 7			
	8	 8			
	9	 9			
	TEXT [=]	 Text / Goto			
	0	 0			
	FAV	 Shift + Fav / Marker / PC			
	VOL+	 Vol+			
	CH+	 CH+ / Page+			
	VOL-	 Vol-			
	CH-	 CH- / Page-			
	MUTE	 Mute / Dimmer			
	RECALL	 Fav / Marker / PC			

	Original	Substitut

