







































































Original	Substitut
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide
 Back	 Back
 P.Mode	 Shift + Format
 S.Mode	 Dual
 Sleep	 Sleep

Original	Substitut
 NICAM	 Smart
 Menu	 Menu
 Source	 AV
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Exit	 Exit
 Display	 Info
 Vol +	 Vol +
 Vol -	 Vol -
 List	 List
 Fav List	 Pre Ch
 CH +	 Ch +
 CH -	 Ch -
 TV / Radio	 TV/R





Original	Substitut	Original	Substitut
CPG	Media		
Aspect	Format		
Freeze	Pause		
Index	D. Menu		
Cancel	Shift + Back		
Subpage	Subt		
Text	Text		
Reveal	Options		
Size	3D		
Hold	Stop		
Mix	Rec		
Red	Red		
Green	Green		
Yellow	Yellow		
Cyan	Blue		

