























Original	Substitut
 Power	 Power
 Mute	 Mute
 Play	 Play
 [=]	 Text
 Pause/[ /≡]	 Pause
 Stop/[≡+]	 Stop
 Rec/[≡◇]	 Rec
 <</[≡o]	 <<
  <</[≡i]	  <<
 >> /[≡?]	 >>
 >>/[≡x]	 >>
 Info	 Info
 EPG	 Guide
 Subtitle	 Subt
 Audio	 Dual
 1	 1
 2	 2

Original	Substitut
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Back	 Back
 Source	 AV



