







































































| Original  | Substitut      | Original  | Substitut      |
|---|----------------|---|----------------|
|      | Power          |      | Power          |
|      | Mute           |      | Mute           |
|      | Source         |      | AV             |
|      | P.Mode         |      | Shift + Format |
|      | S.Mode         |      | Shift + Dual   |
|      | I/II/Audio     |      | Dual           |
|      | Sleep          |      | Sleep          |
|      | 1              |      | 1              |
|      | 2              |      | 2              |
|      | 3              |      | 3              |
|      | 4              |      | 4              |
|     | 5              |     | 5              |
|    | 6              |    | 6              |
|    | 7              |    | 7              |
|    | 8              |    | 8              |
|    | 9              |    | 9              |
|    | 0/10           |    | 0              |
|    | List/+10       |    | Guide          |
|    | Recall/Program |    | Back           |
|    | Tv Menu        |    | Menu           |
|    | Exit           |    | Exit           |
|    | Goto/Text      |    | Text           |
|    | Info/Display   |    | Info           |
|    | Up             |    | Up             |
|    | Down           |    | Down           |
|    | Right          |    | Right          |
|    | Left           |    | Left           |
|    | OK/Enter       |    | Ok             |
|   | P+             |   | Ch +           |
|  | P-             |  | Ch -           |
|  | Vol+           |  | Vol +          |
|  | Vol-           |  | Vol -          |
|  | Red/DVD Setup  |  | Red            |
|  | Green/A-B      |  | Green          |





| Original  |              | Substitut   |               | Original | Substitut |
|---|--------------|---|---------------|----------|-----------|
|    | Yellow/Angle |    | Yellow        |          |           |
|    | Blue/Repeat  |    | Blue          |          |           |
|    | Subtitle     |    | Subt          |          |           |
|    | Play/Hold    |    | Play          |          |           |
|    | Pause        |    | Pause         |          |           |
|    | Size         |    | Format        |          |           |
|    | D.Dis/Reveal |    | 3D            |          |           |
|    | D.Menu/Mix   |    | D. Menu       |          |           |
|    | Zoom/Index   |    | Shift + Eject |          |           |
|    | I<</FAV      |    | I<<           |          |           |
|   | >>I/Subpage  |   | >>I           |          |           |
|  | Stop         |  | Stop          |          |           |
|  | Tv/Radio     |  | TV/R          |          |           |
|  | <<           |  | <<            |          |           |
|  | >>           |  | >>            |          |           |
|  | Eject/EPG    |  | Eject         |          |           |

