
























































































Original	Substitut	Original	Substitut
 Power	 Power	 Info	 Info
 Mute	 Mute	 Exit	 Exit
 Pause	 Pause	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Page+	 Ch +
 6	 6	 Page-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 FAV	 Pre Ch
 0	 0	 Red	 Red
 Recall	 Back	 Green	 Green
 Scan	 Smart	 Yellow	 Yellow
 Menu	 Menu	 Blue	 Blue
 MP	 Media	 SAT	 Options

Original	Substitut	Original	Substitut
 Info	 Info	 TV	 AUX
 Exit	 Exit	 DVD	 SAT
 Up	 Up	 SLEEP	 REPEAT
 Down	 Down	 DUAL	 SUBT
 Right	 Right	 SEARCH	 PICTURE
 Left	 Left	 TV/R	 FORMAT
 OK	 Ok	 E-MANUAL	 ZOOM
 Page+	 Ch +	 D.MENU	 TEXT
 Page-	 Ch -	 TOP MENU	 DISP. INFO
 Vol+	 Vol +	 MENU	 INFO
 Vol-	 Vol -	 OK	 OK
 FAV	 Pre Ch	 EXIT	 RETURN BACK
 Red	 Red	 CLEAR	 HOME
 Green	 Green	 VOL+	 SMART
 Yellow	 Yellow	 VOL-	 APP
 Blue	 Blue	 CH+	 MEDIA
 SAT	 Options	 CH-	 CH-





Original	Substitut	Original	Substitut
 AUDIO	Audio	 SOUND DUAL	Dual
 TV/RADIO	Tv/Radio	 SEARCH TV/R	TV/R

