






























Original	Substitut	Original	Substitut
 ON/OFF	On/Off	 Power	Power
 MUTE	Mute	 MUTE	Mute
 1	1	 1	1
 2	2	 2	2
 3	3	 3	3
 4	4	 4	4
 5	5	 5	5
 6	6	 6	6
 7	7	 7	7
 8	8	 8	8
 9	9	 9	9
 0	0	 0	0
 TV GUIDE	Tv Guide	 GUIDE	Guide
 Recall	Recall	 PRE-CH	Pre Ch
 Vol+	Vol+	 Vol +	Vol +
 Vol-	Vol-	 Vol -	Vol -
 PICTURE	Picture	 PICTURE FORMAT	Format
 SOUND	Sound	 DUAL	Dual
 SOURCE	Source	 AV	AV
 CH+	CH+	 Ch +	Ch +
 CH-	CH-	 Ch -	Ch -
 MENU	Menu	 MENU	Menu
 EXIT	Exit	 EXIT	Exit
 BACK	Back	 BACK	Back
 FAV	FAV	 SHIFT + FAV PRE-CH	Shift + Pre Ch
 Up	Up	 Up	Up
 Down	Down	 Down	Down
 Right	Right	 Right	Right
 Left	Left	 Left	Left
 OK	OK	 OK	Ok
 INFO	Info	 INFO	Info
 TEXT	Text	 TEXT	Text
 SUBTITLE	Subtitle	 SUBT	Subt
 TV	TV	 TV/R	TV/R





Original	Substitut	Original	Substitut
 You Tube	 Media		
 Netflix	 Shift + Media		
 Smart	 Smart		
 Rec/DVD Menu	 Rec		
 I<<	 I<<		
 >>I	 >>I		
 Stop	 Stop		
 Rec List/DVD	 List		
 <<	 <<		
 >>	 >>		
 Play	 Play		
 Pause	 Pause		
 Red/Goto	 Red		
 Green/A-B	 Green		
 Yellow/Angle	 Yellow		
 Blue/Repeat	 Blue		

