




Original	Substitut
	Power
	Input
	Sport
	P.Mode
	S.Mode
	Sleep
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	Guide



































Original	Substitut
	Info
	Vol +
	Vol -
	Mute
	CH.List
	Home
	CH +
	CH -
	*
	[≡]
	Back
	Exit
	Up
	Down
	Right
	Left
	OK





**Original**

**Substitut**

	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	<<		<<
	Play		Play
	>>		>>
	Stop		Stop
	Pause		Pause
	Rec		Rec
	Subtitle		Subt
	Language		Dual
	[++]		3D
	TXT		Text
	YouTube		Shift + Media
	Netflix		Shift + Smart
	Media		Media

**Original**

**Substitut**