







































































| Original | | Substitut | | Original | | Substitut | |
|---|---------|---|--------------------|---|-------------|---|-----------------------|
|  | Power |  | Power |  | V.Menu |  | D.Menu / Top |
|  | Input |  | AV / Input / RDS |  | Menu |  | Menu / Home |
|  | Display |  | Display / Media |  | Vol - |  | Vol- |
|  | P.STD |  | Picture / Format |  | P + |  | CH+ / Page+ |
|  | Mute |  | Mute / Dimmer |  | Vol + |  | Vol+ |
|  | 1 |  | 1 |  | P - |  | CH- / Page- |
|  | 2 |  | 2 |  | << REW |  | << / Tune- |
|  | 3 |  | 3 |  | Stop |  | Stop / Hold |
|  | 4 |  | 4 |  | Play |  | Play / Slow |
|  | 5 |  | 5 |  | >> FF |  | >> / Tune+ |
|  | 6 |  | 6 |  | Rec |  | Rec / Rec Mode |
|  | 7 |  | 7 |  | Eject |  | Eject / Surround |
|  | 8 |  | 8 |  | Pause / P/S |  | Pause / Step / Freeze |
|  | 9 |  | 9 |  | Crystal PB |  | Smart / List |
|  | -/-- |  | Guide / EPG / -/-- |  | TRK Up |  | >> / Preset+ |
|  | 0 |  | 0 |  | TRK Up |  | Up |
|  | Pre-CH |  | Back / Return |  | Index |  | Info / Angle |



