







































































Original	Substitut	Original	Substitut
 Power	 Power	 Stop	 Stop
 Source	 AV	 <<	 <<
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 >>	 >>
 4	 4	 Mute	 Mute
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 P-	 Ch -
 8	 8	 P+	 Ch +
 9	 9	 Menu	 Menu
 0	 0	 Exit	 Exit
 /--	 Guide	 Up	 Up
 PRE-CH	 Pre Ch	 Down	 Down
 TV	 TV/R	 Right	 Right
 CH.MGR	 Smart	 Left	 Left
 Wiselink	 Media	 Enter	 Ok





















































Original	Substitut
[= ?]/Info	Info
[= +]/PIP	3D
TTX/MIX	Text
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
I-II/Dual	Dual
(O)/SRS	Back
Source (Green)	Shift + AV
PC	List
[▼]/STTL	Subt
[<>]/Size	Format
[= ◆]/P.Mode	Shift + Format
[=]/S.Mode	Options
Sleep	Sleep
Power Cable	Shift + Power

Original	Substitut
1 Cable	Shift + 1
2 Cable	Shift + 2
3 Cable	Shift + 3
4 Cable	Shift + 4
5 Cable	Shift + 5
6 Cable	Shift + 6
7 Cable	Shift + 7
8 Cable	Shift + 8
9 Cable	Shift + 9
0 Cable	Shift + 0
P+ Cable	Shift + Ch +
P- Cable	Shift + Ch -





	Original	Substitut		Original	Substitut
	Power		Power		Stop
	1		1		Play
	2		2		Pause
	3		3		>>
	4		4		Menu
	5		5		Exit
	6		6		Up
	7		7		Down
	8		8		Right
	9		9		Left
	0		0		Enter
	PRE-CH		Pre Ch		[≡?]/Info
	TV		TV/R		[<>]/Size
	Sleep		Sleep		Source
	P+		Ch +		
	P-		Ch -		
	<<		<<		



