



Original	Substitut	Original	Substitut
 Power	 Power	 Yellow/Zoom	 Yellow
 Mute	 Mute	 Blue/Option	 Blue
 Rec	 Rec	 Info	 Info
 Goto	 Smart	 FAV	 Pre Ch
 Aspect	 3D	 Menu	 Menu
 V.Format	 Format	 Exit	 Exit
 <<	 <<	 Up/CH+	 Up
 >>	 >>	 Down/CH-	 Down
 Play	 Play	 Right/Vol+	 Right
 Pause	 Pause	 Left/Vol-	 Left
 Stop	 Stop	 OK	 Ok
 Tv/Radio	 TV/R	 Vol+	 Vol +
 Audio	 Dual	 Vol-	 Vol -
 Dev	 Options	 SAT	 Media
 Recall	 Back	 EPG	 Guide
 Red/TTX	 Red	 Page+	 Ch +
 Green/SUB.T	 Green	 Page-	 Ch -

Original	Substitut	Original	Substitut
 TV	 DVD	 SAT	 AUX
 PLAY MODE	 REC MODE	 INFO	 INFO
 LIST	 DUAL	 SUBT	 OPT
 PROG SEARCH	 PICTURE	 ECO	 ECO
 SLEEP	 TV/R	 FORMAT	 3D
 E-MANUAL	 REPEAT	 ZOOM	 TIMER
 D.MENU	 TEXT	 UP	 AV
 TOP MENU	 DISPLAY	 MENU	 INFO
 CLEAR	 EXIT	 UP	 UP
 EXIT	 RETURN	 DOWN	 DOWN
 HOME	 SMART	 RIGHT	 RIGHT
 APP	 MEDIA	 LEFT	 LEFT
 VOL+	 VOL+	 OK	 OK
 VOL-	 VOL-	 VOL+	 VOL+
 SAT	 SAT	 VOL-	 VOL-
 APP	 MEDIA	 SAT	 MEDIA
 EPG	 EPG	 APP	 MEDIA
 PAGE+	 PAGE+	 GUIDE	 GUIDE
 PAGE-	 PAGE-	 VOL+	 VOL+
 PAGE-	 PAGE-	 VOL-	 VOL-



