





















































Original	Substitut	Original	Substitut
On/Off	 Power	Text	 Text
Mute	 Mute	Menu Down	 Down
Update	 +  Shift + Options	Back	 Back
Subt.List	 Subt	Menu	 Menu
Reveal	 Options	Volume+	 Vol +
Menu Up	 Up	Display	 +  Shift + Info
Txt Stop	 Stop	Chan.Up	 Ch +
Menu Left	 Left	Volume-	 Vol -
Info	 Info	Chan.Down	 Ch -
OK Enter	 Ok	1	 1
Sleep Timer	 Sleep	2	 2
Return TV	 TV/R	3	 3
Menu video	 Format	4	 4
Txt Expand	 Eject	5	 5
TV/AV	 AV	6	 6
Menu Right	 Right	7	 7
Menu Off	 Exit	Menu audio	 Dual



Original	Substitut	Original	Substitut
8		8	
9		9	
Guide -/-- 1.		Guide	
0/10		0	
2.Fav P/C 2.		Pre Ch	
Red		Red	
Green		Green	
Yellow		Yellow	
Blue		Blue	
Disp		Smart	
Color- S.Std		Media	
Audio+		D. Menu	
Color+ P.Std		3D	
Bright+ Mode	 +  Shift + 3D		
Off/Tim		List	

