



Original	Substitut	Original	Substitut
 Power	 Power	 Photo	 Shift + 3
 Title	 Options	 All Media	 Shift + 4
 Subtitle	 Subt	 ←Slow	 Back
 SCR Size	 Format	 Stop	 Stop
 Angle	 Red	 Play	 Play
 Repeat	 Text	 Pause	 Pause
 A-B Repeat	 Green	 Up	 Up
 BRT Cont.	 Blue	 Down	 Down
 Device	 Yellow	 Right	 Right
 Menu	 Menu	 Left	 Left
 Setup	 D. Menu	 OK	 Ok
 Info	 Info	 >>	 >>
 Search	 TV/R	 <<	 <<
 Audio	 Dual	 >>	 >>
 Movie	 Shift + 1	 <<	 <<
 Tv Out	 AV	 1/Select	 1
 Music	 Shift + 2	 2/Select All	 2



