




















Original	Substitut	Original	Substitut
 Power	 Power	 16:9	16:9
 Sleep	 Sleep	 Lang	Lang
 Mute	 Mute	 RCL	RCL
 Timer	 AV	 FAV	FAV
 EPI	 Guide	 Page+ / Timeshift	Shift + Ch +
 SUBTL	 Subt	 Page- / V-Format	Shift + Ch -
 Audio	 Shift + Dual	 Page- / V-Format	Shift + Format
 1	 1	 Up / CH+	Up
 2	 2	 Up / CH+	Ch +
 3	 3	 Down / CH-	Down
 4	 4	 Down / CH-	Ch -
 5	 5	 Right / Vol+	Right
 6	 6	 Right / Vol+	Vol +
 7	 7	 Left / Vol-	Left
 8	 8	 Left / Vol-	Vol -
 9	 9	 OK	Ok
 0	 0	 Menu	Menu

Original	Substitut	Original	Substitut
 Format	Format	 Dual	Dual
 Back	Back	 Pre Ch	Pre Ch
 Shift + Ch +	Shift + Ch +	 Shift + Ch -	Shift + Ch -
 Shift + Format	Shift + Format	 Up	Up
 Ch +	Ch +	 Down	Down
 Ch -	Ch -	 Right	Right
 Vol +	Vol +	 Left	Left
 Vol -	Vol -	 Ok	Ok
 Menu	Menu		



