























Original	Substitut
	Mute
	Mute / Dimmer
	Power
	TV
	PROGRAM TV/RADIO
	TV/Radio /
	SHIFT + 2
	SHIFT + PROGRAM TV/RADIO / Program
	SHIFT + REC MODE
	Shift + Rec / Rec Mode
	SHIFT + YouTube / Shift + Yellow / YouTube /
	LANG I/II
	AUDIO
	TV
	1
	DVD
	2
	CD - STB
	3
	VIDEO
	4
	TAPE
	5
	TUNER
	6
	AUX - HDD
	7
	USB
	8
	BLUETOOTH
	9

Original	Substitut
	0/AV
	0
	EPG/DVD-AV
	Guide / EPG / -/-
	ASSIST/Card
	Smart / List
	PIP
	Picture / Format
	Text/Disc-M
	Text / Goto
	Menu
	Menu / Home
	Exit / Cancel / Clear
	End
	Info
	Info / Angle
	Vol+
	Up
	CH+ / Page+
	Left
	OK
	Right
	Vol-
	Down
	CH- / Page-




















Original	Substitut	Original	Substitut
 Red/C-Set	 Red / Netflix / Search		
 Green/SV	 Green / APP / Repeat		
 Yellow/Zoom	 Yellow / YouTube / Repeat		
 Blue/Marker	 Blue / Prime Video / Random		
 <<	 << / Tune-		
 Play	 Play / Slow		
 >>	 >> / Tune+		
 Rec	 Rec / Rec Mode		
 Rec	 Shift + Stop /		
 Pause	 Pause / Step / Freeze		
 Stop	 Stop / Hold		





Original	Substitut
	Mute / Dimmer
	Power
	TV/Radio /
	Shift + 2
	Shift + TV/Radio / Program
	Shift + Rec / Rec Mode
	Shift + Yellow / YouTube / REPEAT A-B
	Audio / Lang I/II
	1
	2
	3
	4
	5
	6
	7
	8
	9

Original	Substitut
	0
	Guide / EPG / -/-
	Smart / List
	Picture / Format
	Text / Goto
	Menu / Home
	Exit / Cancel / Clear
	Info / Angle
	Vol+
	Up
	CH+ / Page+
	Left
	OK
	Right
	Vol-
	Down
	CH- / Page-







































Original	Substitut	Original	Substitut
Red/C-Set	Red / Netflix / Search		
Green/SV	Green / APP / Repeat		
Yellow/Zoom	Yellow / YouTube / Repeat		
Blue/Marker	Blue / Prime Video / Random		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Shift + Stop /		
Rec	Rec / Rec Mode		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		



























Original	Substitut
	 Power
	 Mute / Dimmer
	 Play / Slow
	 Pause / Step / Freeze
	 Stop / Hold
	 Rec / Rec Mode
	 << / Tune-
	 >> / Tune+
	 Audio / Lang I/II
	 Picture / Format
	 TV/Radio /
	 Text / Goto
	 Menu / Home
	 Up
	 Info / Angle
	 Left
	 OK

Original	Substitut
	 Right
	 Exit / Cancel / Clear
	 Down
	 Vol+
	 Smart / List
	 CH+ / Page+
	 Vol-
	 CH- / Page-
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9






























































Original	Substitut	Original	Substitut
 EPG/DVD-AV	 Guide / EPG / -/--		
 0/AV	 0		
 Red/C-Set	 Red / Netflix / Search		
 Green/SV	 Green / APP / Repeat		
 Yellow/Zoom	 Yellow / YouTube / Repeat		
 Blue/Marker	 Blue / Prime Video / Random		
 Rec	 Shift + Stop /		
 Rec Menu	 Shift + Rec / Rec Mode		
 Radio	 Shift + TV/Radio / Program		
 DVD	 Shift + 2		
 - []-/←-AB	 Shift + Yellow / YouTube /		





Original	Substitut	Original	Substitut
Power	 Power	Right	 Right
Mute	 Mute / Dimmer	End	 Exit / Cancel / Clear
Play	 Play / Slow	Down	 Down
Pause	 Pause / Step / Freeze	Vol+	 Vol+
Stop	 Stop / Hold	Assist/Card	 Smart / List
Rec	 Rec / Rec Mode	P+	 CH+ / Page+
<<	 << / Tune-	Vol-	 Vol-
>>	 >> / Tune+	P-	 CH- / Page-
Audio	 Audio / Lang I/II	1	 1
PIP	 Picture / Format	2	 2
TV	 TV/Radio /	3	 3
Text/Disc-M	 Text / Goto	4	 4
Menu	 Menu / Home	5	 5
Up	 Up	6	 6
Info	 Info / Angle	7	 7
Left	 Left	8	 8
OK	 OK	9	 9

Original	Substitut	Original	Substitut
Power	 Power	Right	 Right
Mute	 Mute / Dimmer	End	 Exit / Cancel / Clear
Play	 Play / Slow	Down	 Down
Pause	 Pause / Step / Freeze	Vol+	 Vol+
Stop	 Stop / Hold	Assist/Card	 Smart / List
Rec	 Rec / Rec Mode	P+	 CH+ / Page+
<<	 << / Tune-	Vol-	 Vol-
>>	 >> / Tune+	P-	 CH- / Page-
Audio	 Audio / Lang I/II	1	 1
PIP	 Picture / Format	2	 2
TV	 TV/Radio /	3	 3
Text/Disc-M	 Text / Goto	4	 4
Menu	 Menu / Home	5	 5
Up	 Up	6	 6
Info	 Info / Angle	7	 7
Left	 Left	8	 8
OK	 OK	9	 9





Original	Substitut	
EPG/DVD-AV		Guide / EPG / -/--
0/AV		0
Red/C-Set		Red / Netflix / Search
Green/SV		Green / APP / Repeat
Yellow/Zoom		Yellow / YouTube / Repeat
Blue/Marker		Blue / Prime Video / Random
Rec		Shift + Stop /
Rec Menu		Shift + Rec / Rec Mode
Radio		Shift + TV/Radio / Program
DVD		Shift + 2
- [] / ← AB		Shift + Yellow / YouTube /

Original	Substitut

