






































Original	Substitut	Original	Substitut
 Power	 Power	 Text	 Text / Goto
 Mute	 Mute / Dimmer	 Vol+	 Vol+
 1	 1	 Page+	 Shift + CH+ /
 2	 2	 P+	 CH+ / Page+
 3	 3	 Vol-	 Vol-
 4	 4	 Page-	 Shift + CH- /
 5	 5	 P-	 CH- / Page-
 6	 6	 AD	 Shift + Audio / Lang I/II
 7	 7	 Audio	 Audio / Lang I/II
 8	 8	 Sound	 Sound / Title
 9	 9	 Guide	 Guide / EPG / -/-
 Swap	 Smart / List	 Up	 Up
 0	 0	 Left	 Left
 Back	 Back / Return	 OK	 OK
 FAV	 Fav / Marker / PC	 Right	 Right
 Subtitle	 Subtitle / EQ	 Menu	 Menu / Home
 i	 Info / Angle	 Down	 Down





Original	Substitut	Original	Substitut
 Exit	 Exit / Cancel / Clear		
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		
 Stop	 Stop / Hold		
 Rec	 Rec / Rec Mode		
 <<	 << / Tune-		
 >>	 >> / Tune+		
  <<	  << / Preset-		
 >>	 >>  / Preset+		
 Timer	 Sleep / Timer		
 V-Format	 Picture / Format		
 Media	 Display / Media		
 Aspect	 Zoom / Size		

Original	Substitut	Original	Substitut

