






















































	Original	Substitut		Original	Substitut
	Standby		Power		Source
	Mute		Mute / Dimmer		Menu
	Play / Size		Play / Slow		Up
	Pause /		Pause / Step / Freeze		Left
	Stop / Hold		Stop / Hold		OK
	<<		<< / Tune-		Right
	>>		>> / Tune+		Exit
	<<		<< / Preset-		Down
	>>		>>  / Preset+		Recall
	S.Mode		Sound / Title		Vol+
	Audio		Audio / Lang I/II		CH. List
	Subtitle		Subtitle / EQ		CH+ / Page+
	Pic. Mode		Picture / Format		Vol-
	Sleep		Sleep / Timer		Display
	TV / Radio		TV/Radio /		CH- / Page-
	Index		D.Menu / Top		1
	Text		Text / Goto		2





Original		Substitut	
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	FAV		Fav / Marker / PC
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Aspect		Shift + Picture / Format
	Home		Shift + Menu /
	Reveal		Shift + Back / Return
	Mouse		Shift + Smart / List

Original		Substitut	
	IE		Shift + Display / Media

