





































| Original | Substitut |
|--|--|
|  Power |  Power |
|  Source |  AV |
|  HDMI |  Smart |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -- |  Guide |
|  PRE-CH |  Pre Ch |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |

| Original | Substitut |
|---|--|
|  Mute |  Mute |
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  CH List |  List |
|  Media.P |  Media |
|  Menu |  Menu |
|  FAV.CH |  Shift + Pre Ch |
|  Tools |  Options |
|  Info |  Info |
|  Exit |  Exit |
|  Return |  Back |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  Enter |  Ok |
|  Red |  Red |





| Original | Substitut | Original | Substitut |
|--|--|----------|-----------|
|  Green |  Green | | |
|  Yellow |  Yellow | | |
|  Blue |  Blue | | |
|  S.Mode |  Dual | | |
|  Sleep |  Sleep | | |
|  MTS |  TV/R | | |
|  P.Mode |  Format | | |
|  P.Size |  3D | | |
|  CC |  Subt | | |
|  <<< |  <<< | | |
|  Pause |  Pause | | |
|  >>> |  >>> | | |
|  Rec |  Rec | | |
|  Play |  Play | | |
|  Stop |  Stop | | |
| | | | |
| | | | |

