



	Original	Substitut	Original	Substitut
	Power			EPG
	Mute		MUTE	Mute
	Format		FORMAT	Format
	SAT		HOME SMART	Smart
	TV/STB		APP MEDIA	Media
	TV/Radio		SEARCH TV/R	TV/R
	1		1	1
	2		2	2
	3		3	3
	4		4	4
	5		5	5
	6		6	6
	7		7	7
	8		8	8
	9		9	9
	0		0	0
	Back		RETURN BACK	Back
	EPG		GUIDE	Guide
	Menu		TOP MENU MENU	Menu
	Info		DISPLAY INFO	Info
	Up		Up	Up
	Down		Down	Down
	Right		Right	Right
	Left		Left	Left
	OK		OK	Ok
	Vol+		VOL+	Vol +
	Vol-		VOL-	Vol -
	Exit		CLEAR EXIT	Exit
	CH+ / >>> I		CH+	Ch +
	CH- / I <<<		CH-	Ch -
	Red/Text		A	Red
	Green/Audio		B	Green
	Yellow/Sub.T		C	Yellow
	Blue/Find		D	Blue





	Original	Substitut	Original	Substitut
	Edit	 3D		
	OPT	 Options		
	USB/PVR	 AV		
	FAV	 Pre Ch		
	<<	 <<		
	Play	 Play		
	Pause	 Pause		
	>>	 >>		
	Stop	 Stop		
	Pg Down	 I<<		
	Pg Up	 >>I		
	Rec	 Rec		

