








































































Original	Substitut	Original	Substitut
 Power	 Power	 Sleep	 Sleep
 Mute	 Mute	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 Freeze	 Shift + Media
 3	 3	 View Mode	 Media
 4	 4	 CH+	 Ch +
 5	 5	 CH-	 Ch -
 6	 6	 Surround	 Dual
 7	 7	 MPX	 Format
 8	 8	 Display	 Info
 9	 9	 Menu	 Menu
 0	 0	 Exit	 Exit
 Recall	 Pre Ch	 Return	 Back
 Input	 AV	 Up	 Up
 Tv	 TV/R	 Down	 Down
 PC	 Smart	 Right	 Right
 AV Mode	 3D	 Left	 Left

Original	Substitut	Original	Substitut
 Sleep	 Sleep	 Vol+	 Vol +
 Vol-	 Vol -	 Freeze	 Shift + Media
 View Mode	 Media	 CH+	 Ch +
 CH-	 Ch -	 Surround	 Dual
 MPX	 Format	 Display	 Info
 Menu	 Menu	 Exit	 Exit
 Return	 Back	 Up	 Up
 Down	 Down	 Right	 Right
 Left	 Left		





Original		Substitut		Original	Substitut
	Enter		Ok		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	[≡]		Text		
	[...]		Subt		
	USB		Options		
	Stop		Stop		
	[≡♦]		List		
	[≡+]		Guide		
	<<		<<		
	>>		>>		
	[≡?]		D. Menu		
	[≡o]		Eject		
	Pause		Pause		
	Play		Play		

