
















Original	Substitut	Original	Substitut
MUTE	Mute	MUTE	Mute
POWER	Power	POWER	Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	-/--	Guide
AV	AV	AV	AV
MENU	Menu	MENU	Menu
OK	Red	A	Red
OK	OK	OK	Ok

Original	Substitut	Original	Substitut
P.P	Green	B	Green
P.P	P:P	PRE-CH	Pre Ch
ANALOG	Yellow	C	Yellow
ANALOG	Analog	HOME SMART	Smart
Blue	Blue	D	Blue
P+	Up	Up	Up
P+	P+	+ CH	Ch +
P-	P-	- CH	Ch -
P-	Down	Down	Down
VOL+	Right	Right	Right
VOL+	Vol+	+ VOL	Vol +
VOL-	Vol-	- VOL	Vol -
VOL-	Left	Left	Left
RECALL	Recall	RETURN BACK	Back
SLEEP	Sleep	PROG SLEEP	Sleep
STATUS	Status	ECO 3D	3D
TV/TXT	Tv/TXT	REPEAT TEXT	Text





Original		Substitut	
	Stop		Stop
	Reveal		Media
	Size		Format
	Mix		Options
	Index		Info
	Subcode		Subt
	Cancel		Shift + Back

Original		Substitut	

