





































































Original		Substitut		Original		Substitut	
	Power		Power		6		6
	Open/Close		Eject / Surround		7		7
	V.Mode		Picture / Format		8		8
	OSD		Display / Media		9		9
	P/N		AV / Input / RDS		0		0
	Program		TV/Radio /		10+		Guide / EPG / -/--
	Menu		Menu / Home		Up		Up
	Title		Sound / Title		Down		Down
	Subtitle		Subtitle / EQ		Right		Right
	Angle		Info / Angle		Left		Left
	Search		Red / Netflix / Search		Enter		OK
	Setup		Setup / OPT /		PBC		Text / Goto
	1		1		Return		Back / Return
	2		2		Zoom		Zoom / Size
	3		3		Play		Play / Slow
	4		4		Pause		Pause / Step / Freeze
	5		5		Stop		Stop / Hold





	Original	Substitut	Original	Substitut
	<<	<< / Tune-		
	>>	>> / Tune+		
	I<<	I<< / Preset-		
	>>I	>>I / Preset+		
	Audio	Audio / Lang I/II		
	R/L	D.Menu / Top		
	Slow	+  Shift + Play /		
	Resume	Rec / Rec Mode		
	Reset	Exit / Cancel / Clear		
	Step	+  Shift + Pause / Step /		
	A-B	Yellow / YouTube / Repeat		
	DVD/USB	Smart / List		
	Repeat	Green / APP / Repeat		
	Mute	Mute / Dimmer		
	Vol+	Vol+		
	Vol-	Vol-		

