
















































| Original | Substitut | Original | Substitut |
|---|-----------|---|-----------------------------|
|  | Power |  | Power |
|  | Source |  | AV / Input / RDS |
|  | [=] |  | Text / Goto |
|  | I-II |  | Audio / Lang I/II |
|  | [...] |  | Subtitle / EQ |
|  | Red |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | Menu |  | Menu / Home |
|  | EPG |  | Guide / EPG / -/-- |
|  | Up |  | Up |
|  | << |  | << / Tune- |
|  | Play |  | Play / Slow |
|  | Pause |  | Pause / Step / Freeze |
|  | >> |  | >> / Tune+ |
|  | Down |  | Down |

| Original | Substitut | Original | Substitut |
|---|-------------|---|-----------------------------|
|  | Option |  | Shift + Setup / OPT / Tools |
|  | [i+] |  | Info / Angle |
|  | Vol+ |  | Vol+ |
|  | Stop |  | Stop / Hold |
|  | Page+ |  | CH+ / Page+ |
|  | Vol- |  | Vol- |
|  | Mute |  | Mute / Dimmer |
|  | Page- |  | CH- / Page- |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | FAV |  | Fav / Marker / PC |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | J/Slideshow |  | TV/Radio / |
|  | 7 |  | 7 |



