










































Original	Substitut	Original	Substitut
	Mute		Mute / Dimmer
	Power		Power
	1		1
	2		2
	3		3
	3D		Picture / Format
	4		4
	5		5
	6		6
	Mode		D.Menu / Top
	7		7
	8		8
	9		9
	Zoom		Zoom / Size
	Timer		Sleep / Timer
	0		0
	[+]		Info / Angle

Original	Substitut	Original	Substitut
	Normal		Smart / List
	Input		AV / Input / RDS
	Up		Up
	PR+		CH+ / Page+
	OK[=i]		OK
	Left		Left
	Vol-		Vol-
	Menu		Menu / Home
	Right		Right
	Vol+		Vol+
	[=x]		Subtitle / EQ
	PR-		CH- / Page-
	Down		Down
	[=]		Text / Goto
	[=+]		Setup / OPT /
	[=o]		Audio / Lang I/II
	[=?]		Display / Media





Original	Substitut
 [= ◆]	 TV/Radio /
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random

Original	Substitut

