
























































































































Original	Substitut	Original	Substitut
 Power	 Power	 Tv/Radio	 TV/Radio /
 Mute	 Mute / Dimmer	 i	 Info / Angle
 USB/Media 1	 Display / Media	 Sleep	 Sleep / Timer
 USB/Media 1	 Shift + 8	 Source	 AV / Input / RDS
 Play/Pause/Text	 Text / Goto	 Menu	 Menu / Home
 Play/Pause/Text	 Play / Slow	 Left	 Left
 Play/Pause/Text	 Pause / Step / Freeze	 Up	 Up
 Stop/Index	 Stop / Hold	 Right	 Right
 Rec/Media2	 Rec / Rec Mode	 OK	 OK
 Rec/Media2	 Shift + Display / Media	 Down	 Down
 I<</Hold	 I<< / Preset-	 Mouse	 Shift + OK
 >>I/Size	 >>I / Preset+	 Smart	 Smart / List
 <</S. Page	 << / Tune-	 Exit	 Exit / Cancel / Clear
 >>/Reveal	 >> / Tune+	 CH+	 CH+ / Page+
 I-II/Nicam	 Shift + Picture / Format	 EPG	 Guide / EPG / -/-
 Audio	 Audio / Lang I/II	 VOL+	 Vol+
 Subtitle	 Subtitle / EQ	 CH-	 CH- / Page-





Original	Substitut	Original	Substitut
 Open/Close	 Eject / Surround	 9	 9
 Vol-	 Vol-	 FAV	 Fav / Marker / PC
 D.Setup	 Setup / OPT /	 0	 0
 Picture	 Picture / Format	 Recall	 Back / Return
 D.Menu	 D.Menu / Top	 Red	 Red / Netflix / Search
 Sound	 Sound / Title	 Green	 Green / APP / Repeat
 D.Title	 Shift + Sound / Title	 Yellow	 Yellow / YouTube / Repeat
 P.Size	 Zoom / Size	 Blue	 Blue / Prime Video / Random
 D.Prog	 Shift + TV/Radio / Program		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		

Original	Substitut	Original	Substitut
 9	 9	 9	 9
 FAV	 Fav / Marker / PC	 0	 0
 Recall	 Back / Return	 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat	 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random		

