



| Original                                                                            | Substitut        | Original                                                                            | Substitut             |
|-------------------------------------------------------------------------------------|------------------|-------------------------------------------------------------------------------------|-----------------------|
|    | Power            |    | Power                 |
|    | Mute             |    | Mute / Dimmer         |
|    | Play             |    | Play / Slow           |
|    | Pause            |    | Pause / Step / Freeze |
|    | Stop             |    | Stop / Hold           |
|    | Rec              |    | Rec / Rec Mode        |
|    | <<               |    | << / Tune-            |
|    | >>               |    | >> / Tune+            |
|    | Lang             |    | Audio / Lang I/II     |
|   | Source (Games)   |   | Eject / Surround      |
|  | Movie-Music-Phot |  | Picture / Format      |
|  | [≡]..            |  | Zoom / Size           |
|  | * / O            |  | Sleep / Timer         |
|  | TV               |  | TV / Radio /          |
|  | Q.Menu           |  | D.Menu / Top          |
|  | [-O-]            |  | Setup / OPT /         |
|  | [≡]/Text         |  | Text / Goto           |

| Original                                                                              | Substitut      | Original                                                                              | Substitut             |
|---------------------------------------------------------------------------------------|----------------|---------------------------------------------------------------------------------------|-----------------------|
|    | Menu           |    | Menu / Home           |
|    | Up             |    | Up                    |
|    | i              |    | Info / Angle          |
|    | Left           |    | Left                  |
|    | OK             |    | OK                    |
|    | Right          |    | Right                 |
|    | Exit           |    | Exit / Cancel / Clear |
|    | Down           |    | Down                  |
|    | Back           |    | Back / Return         |
|   | Vol+           |   | Vol+                  |
|  | World (Violet) |  | Smart / List          |
|  | PR+            |  | CH+ / Page+           |
|  | Vol-           |  | Vol-                  |
|  | * / Q          |  | Display / Media       |
|  | PR-            |  | CH- / Page-           |
|  | 1              |  | 1                     |
|  | 2              |  | 2                     |





| Original | Substitut                   |
|----------|-----------------------------|
| 3 def    | 3                           |
| 4 ghi    | 4                           |
| 5 jkl    | 5                           |
| 6 mno    | 6                           |
| 7 pqrs   | 7                           |
| 8 tuv    | 8                           |
| 9 wxyz   | 9                           |
| Guide    | Guide / EPG / -/--          |
| 0        | 0                           |
| Red      | Red / Netflix / Search      |
| Green    | Green / APP / Repeat        |
| Yellow   | Yellow / YouTube / Repeat   |
| Blue     | Blue / Prime Video / Random |
| Recall   | Shift + Back / Return       |
|          |                             |
|          |                             |
|          |                             |

| Original | Substitut |
|----------|-----------|
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |

