











































Original	Substitut	Original	Substitut
 Power	 Power	 Sleep	 Sleep
 Mute	 Mute	 TV/R	 TV/R
 Red / Reset	 Red	 Menu	 Menu
 Green / TXT	 Green	 Exit	 Exit
 Green / TXT	 Text	 Up / CH+	 Up
 Yellow	 Yellow	 Left / Vol-	 Left
 Blue / Panel	 Blue	 OK	 Ok
 <<	 <<	 Right / Vol+	 Right
 >>	 >>	 Down / CH-	 Down
 I<<	 I<<	 SAT	 Media
 >>I	 >>I	 Back	 Back
 Play	 Play	 Vol+	 Vol +
 Pause	 Pause	 Vol-	 Vol -
 Stop	 Stop	 CH+	 Ch +
 Rec	 Rec	 CH-	 Ch -
 FAV	 Pre Ch	 INF	 Info
 Freeze	 Smart	 EPG	 Guide





Original		Substitut		Original		Substitut	
1 1 *+#	1	1	1				
2 2 ABC	2	2	2				
3 3 DEF	3	3	3				
4 4 GHI	4	4	4				
5 5 JKL	5	5	5				
6 6 MNO	6	6	6				
7 7 PQRS	7	7	7				
8 8 TUV	8	8	8				
9 9 WXYZ	9	9	9				
0 0 .-/'	0	0	0				
Func 1	Func 1	SETTINGS OPT	Options				
Stream	Stream	ECO 3D	3D				

