







































































| Original  | Substitut          | Original  | Substitut                   |
|---|--------------------|---|-----------------------------|
|      | Power              |      | Power                       |
|      | Mute               |      | Mute / Dimmer               |
|      | 1                  |      | 1                           |
|      | 2                  |      | 2                           |
|      | 3                  |      | 3                           |
|      | 4                  |      | 4                           |
|      | 5                  |      | 5                           |
|      | 6                  |      | 6                           |
|      | 7                  |      | 7                           |
|     | 8                  |     | 8                           |
|    | 9                  |    | 9                           |
|    | Recall             |    | Back / Return               |
|    | 0                  |    | 0                           |
|    | Info               |    | Info / Angle                |
|    | Menu               |    | Menu / Home                 |
|    | Exit               |    | Exit / Cancel / Clear       |
|    | Up                 |    | Up                          |
|    | Left               |    | Left                        |
|    | OK                 |    | OK                          |
|    | Right              |    | Right                       |
|    | Sat                |    | Shift + 0                   |
|    | Down               |    | Down                        |
|    | FAV                |    | Fav / Marker / PC           |
|    | TV / Radio         |    | TV/Radio /                  |
|    | Guide              |    | Guide / EPG / -/-           |
|    | Freeze             |    | Pause / Step / Freeze       |
|   | Aux In             |   | AV / Input / RDS            |
|  | UHF                |  | Smart / List                |
|  | Red / Audio        |  | Audio / Lang I/II           |
|  | Red / Audio        |  | Red / Netflix / Search      |
|  | Green / Positioner |  | Green / APP / Repeat        |
|  | Yellow / Text      |  | Yellow / YouTube / Repeat   |
|  | Yellow / Text      |  | Text / Goto                 |
|  | Blue / Audio R/L   |  | Blue / Prime Video / Random |



