






































Original	Substitut	Original	Substitut
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Mute		Mute / Dimmer
	0		0
	16:9		Picture / Format
	S/M/D		Display / Media
	PP		Back / Return
	→←		Smart / List
	P+		CH+ / Page+

Original	Substitut	Original	Substitut
	P+		Up
	V-		Vol-
	V-		Left
	Menu		Menu / Home
	Menu		OK
	V+		Vol+
	V+		Right
	P-		CH- / Page-
	P-		Down
	Tv		TV/Radio /
	Exit		Exit / Cancel / Clear
	Av		AV / Input / RDS
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	≡Text		Text / Goto





Original	Substitut
 /≡ Mix	 Audio / Lang I/II
 ☺ Time Page	 Subtitle / EQ
 Info	 Info / Angle
 ≡i	 Guide / EPG / -/--
 ≡+ (PC) Fav / Marker / PC	 Fav / Marker / PC
 ≡◆ (OPT-TOOLS) Setup / OPT /	 Setup / OPT /
 ≡x (SIZE) Cancel	 Zoom / Size
 ≡? (TOP MENU) Reveal	 D.Menu / Top

Original	Substitut

