







































































Original	Substitut	Original	Substitut
 Power	 Power	 EPG	 Guide
 Mute	 Mute	 Sat	 Smart
 1	 1	 Exit	 Exit
 2	 2	 Up	 Up
 3	 3	 Prog +	 Ch +
 4	 4	 Down	 Down
 5	 5	 Prog -	 Ch -
 6	 6	 Right	 Right
 7	 7	 Vol +	 Vol +
 8	 8	 Left	 Left
 9	 9	 Vol -	 Vol -
 0	 0	 Ok	 Ok
 Pause	 Pause	 TV / Radio	 TV/R
 Recall	 Back	 Zoom	 Eject
 Fav	 Pre Ch	 Page -	 I<<<
 Menu	 Menu	 Page -	 <<<
 i	 Info	 PIP	 List

Original	Substitut	Original	Substitut
 MUTE	 MUTE	 SHIFT	 SHIFT
 TV	 TV	 DVD	 DVD
 SAT	 SAT	 AUX	 AUX
 PLAY MODE	 PLAY MODE	 REC MODE	 REC MODE
 FF	 FF	 Stop	 Stop
 PAUSE	 PAUSE	 Play	 Play
 RR	 RR	 Next	 Next
 DISC NAV	 DISC NAV	 SOUND	 AD
 LIST	 LIST	 SUBT	 OPT
 PROG	 PROG	 PICTURE	 ECO
 SLEEP	 SLEEP	 TV/R	 3D
 E-MANUAL	 E-MANUAL	 FORMAT	 TIMER
 D.MENU	 D.MENU	 REPEAT	 ZOOM
 TEXT	 TEXT	 ZOOM	 AV
 TOP MENU	 TOP MENU	 DISPLAY	 INFO
 MENU	 MENU	 OK	 OK
 CLEAR	 CLEAR	 RETURN	 BACK
 EXIT	 EXIT	 HOME	 HOME
 VOL +	 VOL +	 SMART	 SMART
 VOL -	 VOL -	 APP	 APP
 CH +	 CH +	 MEDIA	 MEDIA
 CH -	 CH -	 1	 1
 1	 1	 2	 2
 2	 2	 3	 3
3	3	4	4
4	4	5	5
5	5	6	6
6	6	7	7
7	7	8	8
8	8	9	9
9	9	0	0
0	0	FAV	FAV
GUIDE	GUIDE	PRE-CH	PRE-CH
A	A	B	B
B	B	C	C
C	C	D	D
D	D	Mandis SHOP	Mandis SHOP
www.mandis.tv	www.mandis.tv	www.mandis.tv	www.mandis.tv



