







































































Original	Substitut	Original	Substitut
 Power	 Power	 5	 5
 Mute	 Mute	 6	 6
 Play	 Play	 7	 7
 [=]	 Text	 8	 8
 Pause/[/≡]	 Pause	 9	 9
 Stop/[≡+]	 Stop	 0	 0
 Rec/[≡◆]	 Rec	 Menu	 Menu
 <</[≡0]	 <<	 Exit	 Exit
 <</[≡]	 <<	 Up	 Up
 >> /[≡?]	 >>	 Down	 Down
 >> /[≡x]	 >>	 Right	 Right
 ANT	 Subt	 Left	 Left
 Tools	 Options	 OK	 Ok
 1	 1	 Back	 Back
 2	 2	 Home/Source	 Smart
 3	 3	 Home/Source	 AV
 4	 4	 Vol+	 Vol +





Original		Substitut		Original		Substitut	
	Vol-		Vol -				
	APPS		Media				
	P+		Ch +				
	P-		Ch -				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	EPG		Guide				
	List		List				
	FAV		Pre Ch				
	Info		Info				
	3D		3D				

