










































































Original	Substitut	Original	Substitut
	Power		Power
	Sleep		Sleep / Timer
	Mute		Mute / Dimmer
	Source		AV / Input / RDS
	1		1
	2		2
	3		3
	Audio/Lang		Audio / Lang I/II
	4		4
	5		5
	6		6
	Tv/Radio		TV/Radio /
	7		7
	8		8
	9		9
	Exit		Exit / Cancel / Clear
	CH.List		Smart / List

Original	Substitut	Original	Substitut
	0		0
	Back		Back / Return
	Menu		Menu / Home
	CH-		CH- / Page-
	Up		Up
	CH+		CH+ / Page+
	Left		Left
	Enter		OK
	Right		Right
	Vol-		Vol-
	Down		Down
	Vol+		Vol+
	Setup		Setup / OPT /
	Play/Timeshift		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	Eject		Eject / Surround





Original	Substitut	Original	Substitut
	Rec		Rec / Rec Mode
	Text		Text / Goto
	<<		<< / Tune-
	>>/Reveal		>> / Tune+
	I<</Hold		I<< / Preset-
	>>I/Sub.P		>>I / Preset+
	SUB.T		Subtitle / EQ
	Index/Title		Shift + Sound / Title
	Size/Zoom		Zoom / Size
	D.Menu		D.Menu / Top
	EPG		Guide / EPG / -/--
	FAV/Prog		Fav / Marker / PC
	P.Mode/Lang		Picture / Format
	S.Mode/Search		Sound / Title
	Info/Display		Info / Angle
	Red/Angle		Red / Netflix / Search
	Green/Slow		Green / APP / Repeat

Original	Substitut	Original	Substitut
	Yellow/A-B		Yellow / YouTube / Repeat
	Blue/Repeat		Blue / Prime Video / Random

