







































































| Original | Substitut | Original | Substitut |
|---|------------|---|-----------------------------|
|  | Power |  | Power |
|  | Up |  | Up |
|  | Left |  | Left |
|  | Right |  | Right |
|  | Down |  | Down |
|  | M Menu |  | Menu / Home |
|  | [i] Info |  | Info / Angle |
|  | OK |  | OK |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | P < P |  | Display / Media |
|  | 0 |  | 0 |
|  | Aspect |  | Picture / Format |
|  | Swap |  | Back / Return |
|  | P - / CH - |  | CH- / Page- |
|  | P + / CH + |  | CH+ / Page+ |
|  | Vol - |  | Vol- |
|  | Vol + |  | Vol+ |
|  | Mute |  | Mute / Dimmer |
|  | I - II |  | Audio / Lang I/II |
|  | [TV] |  | Smart / List |
|  | Source |  | AV / Input / RDS |
|  | Red / PIP |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | Text |  | Text / Goto |





| Original | Substitut | Original | Substitut |
|---|-----------|---|-----------------------|
|  | Timer |  | Sleep / Timer |
|  | Hold |  | Stop / Hold |
|  | Cancel |  | Exit / Cancel / Clear |
|  | Mix |  +  | Shift + Text / |
|  | Size |  | Zoom / Size |
|  | Help |  | Setup / OPT / |
|  | Index |  | D.Menu / Top |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

