
































































Original		Substitut		Original		Substitut	
	Power		Power		Favorite		Shift + Pre Ch
	Mute		Mute		Play		Play
	Subtitle		Subt		Pause		Pause
	<<		<<		Stop		Stop
	>>		>>		Info		Info
	l<<		l<<		1		1
	>>l		>>l		2		2
	Record		Rec		3		3
	Up		Up		4		4
	CH+		Ch +		5		5
	CH-		Ch -		6		6
	Down		Down		7		7
	Right		Right		8		8
	Vol+		Vol +		9		9
	Vol-		Vol -		0		0
	Left		Left		EPG		Guide
	OK		Ok		Tv/Radio		TV/R





Original	Substitut	Original	Substitut
 Audio	 Dual		
 Recall	 Pre Ch		
 Repeat	 Shift + Text		
 Teletext	 Text		
 File	 Smart		
 Device	 AV		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Menu	 Menu		
 Exit	 Exit		

