












































































Original	Substitut	Original	Substitut
 Power	 Power	 EPG	 Guide
 Mute	 Mute	 Sat	 Smart
 1	 1	 Exit	 Exit
 2	 2	 Up	 Up
 3	 3	 Prog +	 Ch +
 4	 4	 Down	 Down
 5	 5	 Prog -	 Ch -
 6	 6	 Right	 Right
 7	 7	 Vol +	 Vol +
 8	 8	 Left	 Left
 9	 9	 Vol -	 Vol -
 0	 0	 Ok	 Ok
 Pause	 Pause	 TV / Radio	 TV/R
 Recall	 Back	 Zoom	 Eject
 Fav	 Pre Ch	 Page -	 I<<
 Menu	 Menu	 Page -	 <<
 i	 Info	 PIP	 List

Original	Substitut	Original	Substitut
 MUTE	 MUTE	 SHIFT	
 TV	 DVD	 SAT	 AUX
 PLAY MODE	 REC MODE	 TV	 DVD
 PAUSE	 STOP	 TV	 DVD
 REWIND	 LEFT	 TV	 DVD
 FAST FORWARD	 RIGHT	 TV	 DVD
 STOP	 STOP	 TV	 DVD
 DISC NAV	 SOUND	 TV	 DVD
 LIST	 DUAL	 TV	 DVD
 PROG	 SEARCH	 TV	 DVD
 SLEEP	 TV/R	 TV	 DVD
 E-MANUAL	 REPEAT	 TV	 DVD
 D.MENU	 ZOOM	 TV	 DVD
 D.MENU	 TEXT	 TV	 DVD
 D.MENU	 ZOOM	 TV	 DVD
 D.MENU	 TEXT	 TV	 DVD
 D.MENU	 TEXT	 TV	 DVD
 D.MENU	 TEXT	 TV	 DVD
 D.MENU	 TEXT	 TV	 DVD
 D.MENU	 TEXT	 TV	 DVD
 D.MENU	 TEXT	 TV	 DVD





Original	Substitut	Original	Substitut
	F1		Options
	Page +		>>I
	Page +		>>
	UHF		Format
	P/N		3D
	TV/SAT		Media
	Subtitles		Subt
	Red / Audio		Red
	Audio		Dual
	Green / Mosaic		Green
	Yellow / Clock		Yellow
	Text		Text
	Blue / Text		Blue

Original	Substitut

