



















| Original | | Substitut | | Original | | Substitut | |
|----------|---------|-----------|------------------|----------|-------------------|-----------|-----------------------|
| | Power | | Power | | 7 | | 7 |
| | Mute | | Mute / Dimmer | | 8 | | 8 |
| | Vol- | | Vol- | | 9 | | 9 |
| | Vol+ | | Vol+ | | 0 | | 0 |
| | P- | | CH- / Page- | | -/-- | | Guide / EPG / -/-- |
| | P+ | | CH+ / Page+ | | Contrast- | | I<< / Preset- |
| | Power 2 | | Shift + Power | | Contrast+ | | >>I / Preset+ |
| | [+] | | Display / Media | | Brightness- | | Down |
| | PP | | Back / Return | | Brightness+ | | Up |
| | [] | | Info / Angle | | Text | | Text / Goto |
| | []↔ | | Picture / Format | | Text Subcode | | Subtitle / EQ |
| | 1 | | 1 | | Text Hold | | Shift + Stop / |
| | 2 | | 2 | | Text Size | | Zoom / Size |
| | 3 | | 3 | | Text Reveal | | Smart / List |
| | 4 | | 4 | | Text Index / Play | | Play / Slow |
| | 5 | | 5 | | Text Mix | | Shift + Text / |
| | 6 | | 6 | | Text Cancel | | Exit / Cancel / Clear |





| Original | Substitut | Original | Substitut |
|--|---|----------|-----------|
|  Red / Rec |  Red / Netflix / Search | | |
|  Red / Rec |  Rec / Rec Mode | | |
|  Green / Stop |  Green / APP / Repeat | | |
|  Green / Stop |  Stop / Hold | | |
|  Yellow / << |  Yellow / YouTube / Repeat | | |
|  Yellow / << |  << / Tune- | | |
|  Blue / >> |  Blue / Prime Video / Random | | |
|  Blue / >> |  >> / Tune+ | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





| Original | | Substitut | | Original | | Substitut | |
|----------|---------|-----------|------------------|----------|--------------|-----------|-----------------------|
| | Power | | Power | | 7 | | 7 |
| | Mute | | Mute / Dimmer | | 8 | | 8 |
| | Vol- | | Vol- | | 9 | | 9 |
| | Vol+ | | Vol+ | | 0 | | 0 |
| | P- | | CH- / Page- | | -/-- | | Guide / EPG / -/-- |
| | P+ | | CH+ / Page+ | | Text | | Text / Goto |
| | Power 2 | | Shift + Power | | Text Subcode | | Subtitle / EQ |
| | [+] | | Display / Media | | Text Hold | | Shift + Stop / |
| | PP | | Back / Return | | Text Size | | Zoom / Size |
| | [] | | Info / Angle | | Text Reveal | | Smart / List |
| | []↔ | | Picture / Format | | Play | | Play / Slow |
| | 1 | | 1 | | Text Mix | | Shift + Text / |
| | 2 | | 2 | | Text Cancel | | Exit / Cancel / Clear |
| | 3 | | 3 | | Rec | | Rec / Rec Mode |
| | 4 | | 4 | | Stop | | Stop / Hold |
| | 5 | | 5 | | << | | << / Tune- |
| | 6 | | 6 | | >> | | >> / Tune+ |

