





| Original | Substitut | Original | Substitut |
|---|--------------|---|---------------------------|
|  | Setup |  | Setup / OPT / |
|  | Display |  | Display / Media |
|  | Zoom |  | Zoom / Size |
|  | Sub |  | Subtitle / EQ |
|  | I<< |  | I<< / Preset- |
|  | Up |  | Up |
|  | >>I |  | >>I / Preset+ |
|  | A-B Repeat |  | Yellow / YouTube / Repeat |
|  | << |  | << / Tune- |
|  | Left |  | Left |
|  | Enter |  | OK |
|  | >> |  | >> / Tune+ |
|  | Right |  | Right |
|  | 1/All Repeat |  | Green / APP / Repeat |
|  | 0 |  | 0 |
|  | Down |  | Down |
|  | Stop |  | Stop / Hold |

| Original | Substitut | Original | Substitut |
|---|-----------|---|-----------------------|
|  | Menu |  | Menu / Home |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | Audio |  | Audio / Lang I/II |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | Angle |  | Info / Angle |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | Play |  | Play / Slow |
|  | Pause |  | Pause / Step / Freeze |
| | | | |
| | | | |
| | | | |

