





































Original	Substitut	Original	Substitut
	Power		Power
	Input		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Guide		Guide
	Subtitle		Subt
	Red		Red
	Green		Green
	Yellow		Yellow

Original	Substitut	Original	Substitut
	Blue		Blue
	[≡]		Menu
	Back		Back
	TXT		Text
	Exit		Exit
	Home		Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	CH+		Ch +
	CH-		Ch -
	CH List		List





Original	Substitut
<<	<<
Play	Play
>>	>>
Pause	Pause
Stop	Stop
Audio Only	Dual
[++]	Options
YouTube	Media
Netflix	Shift + Smart
Rakuten Tv	Shift + Media

Original	Substitut

