



Original	Substitut
 Power	 Power
 Top Menu	 D.Menu / Top
 Guide	 Guide / EPG / -/--
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down
 Back	 Back / Return
 Exit	 Exit / Cancel / Clear
 Zoom	 Zoom / Size
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 P+	 CH+ / Page+

Original	Substitut
 AV	 AV / Input / RDS
 Vol+	 Vol+
 P-	 CH- / Page-
 Mute	 Mute / Dimmer
 Vol-	 Vol-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 i	 Info / Angle
 0	 0
 [≡]	 Text / Goto





	Original	Substitut	Original	Substitut
	DTV	 Display / Media		
	ATV	 Smart / List		
	Radio	 TV/Radio /		
	♪	 Sound / Title		
	[?]	 Setup / OPT /		
	[...]	 Subtitle / EQ		
	O/I/II	 Audio / Lang I/II		
	Timer	 Sleep / Timer		

