







































































Original	Substitut	Original	Substitut
 Power	 Power	 Vol +	 Vol +
 Energy Saving	 3D	 Vol -	 Vol -
 Ratio	 Format	 FAV / Mark	 Pre Ch
 Input	 AV	 Mute	 Mute
 TV/RAD	 TV/R	 P+ / Page +	 Ch +
 Menu	 Menu	 P- / Page -	 Ch -
 Q.Menu	 D. Menu	 1	 1
 Guide	 Guide	 2	 2
 Up	 Up	 3	 3
 Left	 Left	 4	 4
 OK	 Ok	 5	 5
 Right	 Right	 6	 6
 Down	 Down	 7	 7
 Return / Exit	 Back	 8	 8
 Return / Exit	 Exit	 9	 9
 Info	 Info	 0	 0
 AV Mode	 Shift + AV	 List	 List





Original		Substitut	
	Q.View		Smart
	Red		Red
	Green / Stop		Green
	Green / Stop		Stop
	Yellow / Play		Yellow
	Yellow / Play		Play
	Blue / Pause		Blue
	Blue / Pause		Pause
	Text		Text
	T.Opt / <<		Options
	T.Opt / <<		<<
	Subtitle / >>		Subt
	Subtitle / >>		>>
	Simplink		Media
	Freeze	+	Shift + Pause

Original	Substitut

