















































Original	Substitut
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 List	 Smart / List
 0	 0
 Recall	 Back / Return
 Vol+	 Vol+
 Sleep	 Sleep / Timer
 CH+	 CH+ / Page+

Original	Substitut
 Vol-	 Vol-
 Prog	 Shift + TV/Radio / Program
 CH-	 CH- / Page-
 Aspect	 Shift + Picture / Format
 S.Mode	 Sound / Title
 P.Mode	 Picture / Format
 Guide/Title	 Guide / EPG / -/-
 Guide/Title	 Shift + Sound / Title
 Menu	 Menu / Home
 Up	 Up
 Input	 AV / Input / RDS
 Left	 Left
 OK	 OK
 Right	 Right
 Freeze	 Shift + Pause / Step /
 Down	 Down
 Exit	 Exit / Cancel / Clear





Original	Substitut	Original	Substitut
	i		Info / Angle
	FAV/Setup		Fav / Marker / PC
	FAV/Setup		Setup / OPT /
	Tv/RD/Angle		Shift + Info / Angle
	Tv/RD/Angle		TV/Radio /
	AD		Audio / Lang I/II
	Text/Menu		Text / Goto
	Text/Menu		D.Menu / Top
	↑		Shift + Up
	S		Display / Media
	Zoom / Rec		Zoom / Size
	Zoom / Rec		Rec / Rec Mode
	←/Cancel		Shift + Left
	←/Cancel		Shift + Exit / Cancel / Clear
	OK/Mix		Shift + OK
	→/Size		Shift + Right
	→/Size		Shift + Zoom / Size

Original	Substitut	Original	Substitut
	Stop		Stop / Hold
	Eject		Eject / Surround
	↓		Shift + Down
	Play		Play / Slow
	Pause/Step		Pause / Step / Freeze
	I<</Hold		I<< / Preset-
	I<</Hold		Shift + Stop /
	>>I/Reveal		>>I / Preset+
	<</Subpage		<< / Tune-
	>>/Index		>> / Tune+
	Red/Goto		Shift + Text /
	Red/Goto		Red / Netflix / Search
	Green/Slow		Green / APP / Repeat
	Green/Slow		Shift + Play /
	Yellow/Repeat		Shift + Green / APP /
	Yellow/Repeat		Yellow / YouTube / Repeat
	Blue/A-B		Shift + Yellow / YouTube / Repeat





