
















































































































Original	Substitut	Original	Substitut
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 Play	Menu Off	 Exit
Reveal	 Pause	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Rec	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 List
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7



Original	Substitut	
8		8
9		9
Guide -/-- 1.		Guide
0/10		0
2.Fav P/C 2.		Pre Ch
Red		Red
Green		Green
Yellow		Yellow
Blue		Blue
Rotate Text	 + 	Shift + Mute
Audio-	 + 	Shift + Vol -
Tone-		Media
Audio+	 + 	Shift + Vol +
Color+ P.Std	 + 	Shift + Format
On/Tim	 + 	Shift + Subt
Store Text	 + 	Shift + Text
AV 2	 + 	Shift + AV

Original	Substitut	
Search	 + 	Shift + TV/R
Bright+ Mode	 + 	Shift + Menu
Disp	 + 	Shift + Info
Tune-	 + 	Shift + Left
Aft/Caf	 + 	Shift + Ok
Store		Smart
Tune+	 + 	Shift + Right
Bright- Sys	 + 	Shift + Exit
Contrast+	 + 	Shift + Ch +
Color- S.Std		Dual
Contrast-	 + 	Shift + Ch -
3.*	 + 	Shift + Guide
Nicam/Mono	 + 	Shift + Green
Level L	 + 	Shift + Yellow
Level R/Woofer	 + 	Shift + Blue
4.# 16:9		Format



Original	Substitut	Original	Substitut
Power		Power	
Recall		Up	
1		Left	
2		OK	
3		Right	
4		Down	
5		Vol +	
6		Vol -	
7		LCD Menu	
8		Exit / DVD Setup	
9		Exit / DVD Setup	
0		D.Menu	
AV / Input		D.Disp	
-/--		Red / Prog	
EPG		Green / Intro	
P +		Yellow / Repeat	
P -		Blue / A-B	



Original	Substitut	Original	Substitut
Title	Smart	>>I / Hold	+ Shift + Stop
Eject / PC Auto	+ Shift + Exit	Reveal / Angle	Format
<< / Index	<<	Subpage /	Eject
Play/Pause / Fav	Play	Lang / Audio	+ Shift + Dual
Play/Pause / Fav	Pre Ch	□ / Goto	TV/R
>> / Size	>>	Subtitle	Subt
Rec / S.Mode	Rec	Info	Info
Rec / S.Mode	Dual		
Step >I / Fav +	+ Shift + Play		
Step >I / Fav +	+ Shift + Up		
Pause / P.Mode	Pause		
Pause / P.Mode	+ Shift + Format		
I<< / Text	I<<		
I<< / Text	Text		
Stop / Fav -	Stop		
Stop / Fav -	+ Shift + Down		
>>I / Hold	>>I		

