





Original	Substitut
	Mute / Dimmer
	Fav / Marker / PC
	Power
	Info / Angle
	Smart / List
	1
	2
	3
	Stop / Hold
	4
	5
	6
	Subtitle / EQ
	7
	8
	9
	Display / Media

Original	Substitut
	AV / Input / RDS
	0
	Guide / EPG / +/-
	Shift + Text /
	Text / Goto
	CH+ / Page+
	Up
	Menu / Home
	Left
	Vol-
	OK
	Right
	Vol+
	Back / Return
	CH- / Page-
	Down
	Setup / OPT /





Original	Substitut
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow / Timer	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Violet	Shift + Red / Netflix /
Picture	Picture / Format
Music	Sound / Title
PP	Exit / Cancel / Clear

Original	Substitut

