






Original	Substitut	Original	Substitut
	Mute		Mute / Dimmer
	TV/SAT		AV / Input / RDS
	Standby		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Sat List		Smart / List
	0		0
	TV/R		TV/Radio /
	CH-PG+		CH+ / Page+
	EPG		Guide / EPG / -/-

Original	Substitut	Original	Substitut
	Vol+		Vol+
	CH/PG-		CH- / Page-
	FAV		Fav / Marker / PC
	Vol-		Vol-
	Info		Info / Angle
	Up		Up
	Menu		Menu / Home
	Left		Left
	OK		OK
	Right		Right
	Back		Back / Return
	Down		Down
	Exit		Exit / Cancel / Clear
	Red / Audio		Red / Netflix / Search
	Red / Audio		Audio / Lang I/II
	Green / Subt		Green / APP / Repeat
	Green / Subt		Subtitle / EQ




**Original**
**Substitut**

	Yellow / Text		Text / Goto
	Yellow / Text		Yellow / YouTube / Repeat
	Blue / Sleep		Blue / Prime Video / Random
	Blue / Sleep		Sleep / Timer
	Option 1		D.Menu / Top
	Option 2		Setup / OPT /
	Pal / NTSC		Picture / Format
	Pause		Stop / Hold
	Freeze		Pause / Step / Freeze
	Zoom		Zoom / Size

**Original**
**Substitut**