





| Original | Substitut | Original | Substitut |
|---|-----------|---|-----------|
|  | Power |  | Power |
|  | [≡] |  | Text |
|  | Sleep |  | Sleep |
|  | Color |  | Options |
|  | [+]/◆ |  | Info |
|  | ? |  | Smart |
|  | 16:9/[+] |  | Format |
|  | I-II/[≡i] |  | Dual |
|  | (<>)/X |  | Exit |
|  | Up |  | Up |
|  | P+ |  | Ch + |
|  | P- |  | Ch - |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Vol+ |  | Vol + |
|  | Left |  | Left |
|  | Vol- |  | Vol - |

| Original | Substitut | Original | Substitut |
|---|---------------|---|----------------|
|  | Menu |  | Menu |
|  | Menu |  | Ok |
|  | Inst |  | Media |
|  | Source |  | AV |
|  | P<P |  | Pre Ch |
|  | Red/Picture |  | Red |
|  | Picture |  | Shift + Format |
|  | Green/Sound |  | Green |
|  | Sound |  | Shift + Dual |
|  | Yellow/Timer |  | Yellow |
|  | Timer |  | Shift + AV |
|  | Blue/Headphon |  | Blue |
|  | Headphones |  | List |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |



